

DECORATIVE MILLWORK -

A NOVO Building Products Company

CRAFTSMAN STYLE



Quick and easy upgrade

Creates a Build Up look Lightweight and easy to install

Crossheads available to fit 5 common door widths



Installation Instructions

- 1. LOCATE AND MARK STUDS ABOVE DOOR.
- 2. APPLY ADHESIVE BEAD ON THE BACK OF CROSSHEAD.
- 3. POSITION CROSSHEAD ABOVE CASING ALIGNING WITH EQUAL SPACING ON EITHER SIDE.
- 4. SECURE WITH FINISHING NAILS INTO STUDS.

NOTE: BEST USED WITH A 4" NOMINAL OR LESS WIDE CASING.

